

Zebra ZC300 Firmware Update (For Windows)


- Create a Zebra Account (You **MUST** create a Zebra Account otherwise it's not possible to download the latest firmware file).
 - [Create Zebra Account](#)

- Download the latest firmware.
 - [Download Link](#)


- Download and install the latest Zebra ZC300 driver.
 - [Download Link](#)

- [Link to install ZC300 driver](#)


- Go to **Devices and Printers** right click on the printer select **Printer properties**.




- Click **Settings** to open Zebra ZC300 Configuration Window.




- Zebra ZC300 Configuration Windows opens.
- Click **Advanced**.




- Click **Configuration Firmware and Settings**.




- Click on the **folder icon** to select the firmware file.




- Select the firmware file click **Open**.




- Now the firmware file has been selected and is ready to be downloaded to the printer.
- Click **Update**.




- Make sure you have selected the correct firmware version.
- Click **OK**.




- **Don't** turn off the printer during the firmware update.
- Click **OK**.



- The firmware updating has started.



- Firmware update initializing - be patience.



- Firmware update is done.
- Click **Close**.

